

Supplement 4/62

to Spare Parts List Type 3

New parts:

113 127 117 A	Fuel pump rocker arm (one-piece) (see Workshop Bulletin)	
113 127 131 A	Return spring (for 113 127 117 A)	
311 255 103	Heat exchanger	
311 255 104	Heat exchanger (with sprayed-on insulation)	
361 813 251	Retaining strap	
311 813 327 A	Extension	
311 813 328 A	Extension (to simplify repairs)	
311 863 021	Lining – Front panel	426
311 863 022	Lining – Front panel	426
312 863 022	Lining – Front panel (RHD) (with side member mat)	426
361 863 883	Sound absorber front	
361 863 884	Sound absorber front	
361 863 885	Sound absorber rear	
361 863 886	Sound absorber rear (now available as spare part)	
313 867 503	Lining – Roof	374
313 867 549	Retaining spring (for sliding roof Sedans)	
311 881 223	Arm	
311 881 247	Clip	
311 881 251	Fingerpull (now available as spare part)	
K 374 13 B	Leatherette (now available as spare part)	
311 885 305 A	Spring core	
361 885 305	Spring core	
361 885 375	Padding	
361 885 533 C	Beading	
361 885 569	Pivot rod	
361 885 570	Pivot rod	
361 885 593	Cover plate	
311 885 705 C	Spring core	
361 885 705	Spring core	
361 885 775	Padding (now available as spare part)	

No longer available:

311 209 185 superseded by: 211 209 187
311 255 105 superseded by: 311 255 103
311 255 106 superseded by: 311 255 104
311 255 357 A superseded by: 311 255 355 A
311 255 358 A superseded by: 311 255 356 A
311 821 141 superseded by: N 10 216 2
361 821 334 superseded by: 361 821 333
361 827 499 no longer available
312 845 101 superseded by: 311 845 101
311 863 023 superseded by: 311 863 021
311 863 024 superseded by: 311 863 022
312 863 024 superseded by: 312 863 022
311 885 305 superseded by: 311 885 305 A
361 885 533 B superseded by: 361 885 533 C
311 885 705 B superseded by: 311 885 705 C

Delete:

311 700 041 superseded by: 361 700 041